



Nonesuch Lounge Chair



DESIGNED IN 2017

ASSEMBLY NOTES | REV 02




MESSAGE YOUR EYEBALLS.

What you see is what you get. Graceful contours of 3D bent ply that stun from all angles. What you can't see is that this lounge is a pleasure to sit in.

NEED A HAND?

Contact us at service@bludot.com or **844.425.8368** for assistance.

Parts & Hardware



QTY

4


QTY

4


QTY

1


Pt. 1068



Pt. 3001




Pt. 9022



QTY

1

Shell



QTY



1

Base


Step 01

ATTACH BASE.


Place chair shell on soft surface as shown.
Attach the base using the provided hardware
as shown.



PT. 1068 x 4



PT. 3001 x 4



PT. 9022 x 1

Additional Information

CLEAN

Vacuum your upholstery regularly. Clean with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulate for wood furniture. Wipe completely dry with a soft cloth in the direction of the wood grain.

SPILLS

Act quickly with spills. Absorb the spill with a clean white cloth or paper towel. Never rub the surface. Do not use water or other liquids to clean, as they may stain the fabric. Consult a commercial cleaning specialist for removal of stubborn stains.

AVOID

Keep upholstery & felt furniture out of direct sunlight and away from heat sources; excessive exposure to sunlight may fade the color of the upholstery. Avoid placing heavy or sharp objects on the furniture surface for long periods of time; this can cause permanent indentations in the fabric. For snags in the fabric, tuck loose threads into fabric or carefully push to reverse side. Never pull out or cut off loose threads.

