


**BLU  
DOT**

# SHALE

**SM CREDENZA,  
LG CREDENZA, &  
LOW DRESSER**  
Assembly Notes

**NO CURSING  
REQUIRED.**



## CARE


Clean with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for wood furniture. Wipe completely dry with a soft cloth in the direction of the wood grain.



## DOOR ALIGNMENT

HINGES WORK IN UNISON WITH ONE ANOTHER, MEANING IF YOU ADJUST ONE HINGE CHANCES ARE YOU WILL HAVE TO ADJUST ALL THE HINGES. THINK OF IT AS A BALANCING ACT BETWEEN THE DOOR AND ITS HINGES.

IF DOOR NEEDS ADJUSTMENT FROM TOP TO BOTTOM, ADJUST DOOR USING SCREW #3



**SCREW #1**

**SCREW #2**

**SCREW #3**