
Verge Hardwired Sconce

DESIGNED IN 2021

ASSEMBLY NOTES | REV 00






NEED A HAND?

Contact us at **service@bludot.com** or **844.425.8368** for assistance.

@BLUDOT

We design all our pieces in our Minneapolis studio. Follow along on Instagram for some sneak peeks into the process.

Parts & Hardware




Electricity is dangerous. It is recommended to hire a professional electrician to install hard-wired fixtures.

1 | 844.425.8368 VERGE HARDWIRED SCONCE

DETACH WALL BRACKET.

The lamp ships with the wall bracket attached to the lamp body. Carefully detach the wall bracket by unscrewing the two screws and set parts aside for assembly in later steps.




ASSEMBLY NOTES SERVICE@BLUDOT.COM | 2

INSTALL WALL BRACKET

Disconnect power before proceeding with installation.

Attach the wall bracket to the wall electrical box as shown using the provided hardware.




3 | 844.425.8368 VERGE HARDWIRED SCONCE

JOIN ELECTRICAL WIRES

Twist white wires together and secure in place using provided wire nut.

Twist black wires together and secure in place using provided wire nut.






ASSEMBLY NOTES SERVICE@BLUDOT.COM | 4

GROUND SCONCE.

Locate bare copper ground wire inside lamp body.

Twist ground wires together and secure in place using provided wire nut.

If no green wire (ground wire) is present in the electrical box, wrap wire around preattached screw on wall bracket and tighten into place.






5 | 844.425.8368 VERGE HARDWIRED SCONCE


INSTALL LAMP BODY.

Carefully tuck the wiring into the electrical box and gently position lamp body over wall bracket.

Use provided hardware to secure lamp body in place as shown.

Re-connect power to complete installation.





ASSEMBLY NOTES SERVICE@BLUDOT.COM | 6

Additional Information

USE

This unit is meant for indoor use in dry locations only.

CLEAN

Clean powder-coated surfaces with a dry soft cloth or sponge.

REGULATORY

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

